

## 微差圧トランスミッター PDT102/PDT101

### PDT102

| 注文コード       | 電源         | 測定範囲                      | 出力       |  |
|-------------|------------|---------------------------|----------|--|
| PDT102-P2C  | 12...36VDC | ±50 Pa                    | 4...20mA |  |
| PDT102-P2CT | 12...36VDC | ±50 Pa                    | 4...20mA |  |
| PDT102-P2V  | 12...36VDC | ±50 Pa                    | 0...5V   |  |
| PDT102-P2VT | 12...36VDC | ±50 Pa                    | 0...5V   |  |
| PDT102-P5C  | 12...36VDC | ±50 Pa                    | 4...20mA |  |
| PDT102-P5CT | 12...36VDC | ±50 Pa                    | 4...20mA |  |
| PDT102-P5V  | 12...36VDC | ±50 Pa                    | 0...5V   |  |
| PDT102-P5VT | 12...36VDC | ±50 Pa                    | 0...5V   |  |
| PDT102-W2C  | 12...36VDC | ±0.25 in H <sub>2</sub> O | 4...20mA |  |
| PDT102-W2CT | 12...36VDC | ±0.25 in H <sub>2</sub> O | 4...20mA |  |
| PDT102-W2V  | 12...36VDC | ±0.25 in H <sub>2</sub> O | 0...5V   |  |
| PDT102-W2VT | 12...36VDC | ±0.25 in H <sub>2</sub> O | 0...5V   |  |
| PDT102-W5C  | 12...36VDC | ±0.25 in H <sub>2</sub> O | 4...20mA |  |
| PDT102-W5CT | 12...36VDC | ±0.25 in H <sub>2</sub> O | 4...20mA |  |
| PDT102-W5V  | 12...36VDC | ±0.25 in H <sub>2</sub> O | 0...5V   |  |
| PDT102-W5VT | 12...36VDC | ±0.25 in H <sub>2</sub> O | 0...5V   |  |

電源は、24VDCをお勧めします。

### PDT101

| 注文コード      | 電源           | 温度測定範囲                    | 出力       |  |
|------------|--------------|---------------------------|----------|--|
| PDT101-P4C | 12...36VDC   | ±60 Pa                    | 4...20mA |  |
| PDT101-P4V | 12...36VDC   | ±60 Pa                    | 0...5V   |  |
| PDT101-W4C | 11.5...36VDC | ±0.25 in H <sub>2</sub> O | 4...20mA |  |
| PDT101-W4V | 11.5...36VDC | ±0.25 in H <sub>2</sub> O | 0...5V   |  |