

Vaisala Cirrus® Sounding System MW51 – Software Version Number

- For finding MW51 Sounding System / DigiCORA software version number in the user interface, select Help > About. The version number is shown on the dialog.
- For finding MW51 Sounding System / DigiCORA software version number from an archived sounding data set, proceed as follows:
 - Find the compressed sounding data set file *.digicora
 - Open file software_version.xml
 - Find the software version from the file content: `calculations_software_version="5.x.x-xx"`
- MW51 Sounding System / DigiCORA software version number is added to BUFR messages 3 09 052, 3 09 057, and 3 09 056. The element is 0 25 061 Software identification and version number.
 - The format of the version number is: DC 5.x.x