

**Vaisala Ultrasonic Wind Sensor
WMT700**

WMT 700																			
1	Measurement range	90 m/s	WMT704	4	D														
2	Temperature range	-10...+60 C			A														
		-40...+60 C			B														
		-55...+70 C			C														
3	Heating	Non-heated version			1														
		Heated transducers			2														
		Heated transducers and arms			3														
		Heated transducers, arms and body			4														
4	Digital communication interface	RS-485 isolated			A														
		RS-422 isolated			B														
		RS-232 isolated			C														
		SDI-12 isolated			D														
5	Digital communication profile	WMT70 - poll mode (default)	9600b, 8, N, 1 Polled		0														
		WS425 - ASCII	2400b, 8, N, 1 Polled		1														
		WS425 - NMEA Extended (v 0183)	9600b, 8, N, 1 Auto send 1/s		2														
		WS425 - SDI-12 (v 1.3)	1200b, 7, E, 1 Polled		3														
		WS425 - ASOS	2400b, 8, N, 1 Polled		4														
		ROSA - MES12	9600b, 8, N, 1 Polled		5														
		AWS520 - NMEA Extended (v 0183)	4800b, 8, N, 1 Auto send 1/s		8														
6	Digital communication units	m/s			A														
		knots			B														
		mph			C														
		km/h			D														
7	Analog output signals for wind speed channel	Disabled			0														
		Voltage output	100 mV/m/s		1														
		Current output	4...20 mA (0...Range m/s)		3														
		Current output	0.2 mA/m/s		4														
		Push-Pull frequency output	10 Hz/m/s		6														
		WS425 - voltage output	8 mV/mp/h		7														
		WS425 - frequency output (Push-Pull)	5 Hz/mp/h		8														
		Pull up frequency output (PNP)	10 Hz/m/s		A														
		Pull down frequency output (NPN)	10 Hz/m/s		B														
8	Analog output signals for wind direction channel	Disabled			0														
		Voltage output	20 mV/Deg		A														
		Current output	50 uA/Deg		D														
		Current output 4...20 mA	44.444 uA/Deg		E														
		Potentiometer output (WS425)	0...Vref (Vref = external reference voltage from system)		F														
9	Cable	None			1														
		Cable 2 m, cable connector, open leads on one end			2														
		Cable 10 m, cable connector, open leads on one end			3														
		MAWS cable 10 m			4														
		AWS520 cable 10 m, shield connected to PE pin			5														
		Adapter cable for WS425 serial			6														
		Adapter cable for WS425 analog frequency output			7														
		RS485 Cable 2 m, cable connector, open leads on one end			8														
		RS485 Cable 10 m, cable connector, open leads on one end			9														
		Adapter cable for WS425 analog voltage output			A														
		AWS520 cable 10 m, shield not connected to PE pin			B														
		ROSA analog cable 10 m, cable connector, open leads on one end			C														
		Junction Box with Cable 2meters			D														
		Cable 15 m, cable connector, open leads on one end			E														
		Cable 26 m, cable connector, open leads on one end			F														
10	Mounting adapter	Adapter 228869 only																	
		Adapter 228869 with WMT700FIX70 (suitable also for inverted mounting)																	
		Adapter 228869 with WMT700FIX60-POM																	
		Adapter 228869 with WMT700FIX60-RST																	
		Adapter 228777 only (used for old WS425 FIX30/60)																	
11	Power - Reserved for future purposes	None																	
12	Accessories	None																	
		Bird cage																	
13	Manual	None																	
		English																	
		Japanese																	
		Chinese																	
		Russian																	
		DEIF																	
		French																	
		Spanish																	

For freezing conditions select appropriate combination of heating and temperature ranges.

Accessories

Tool	Verifier	WMT70Verifier
	Cable Tightener Tool	237888SP
Bird	Bird cage	WMT70BirdKit
	Bird perch	WS425BirdPerch
Cable	Cable connector	WMT70Conn
	Cable 2 m, cable connector, open leads on one end	227567SP
	Cable 10 m, cable connector, open leads on one end	227568SP
	Cable 15 m, cable connector, open leads on one end	237890SP
	Cable 26 m, cable connector, open leads on one end	237899SP
	RS485 Cable 2 m, cable connector, open leads on one end	228298SP
	RS485 Cable 10 m, cable connector, open leads on one end	228260SP
	MAWS cable 10 m	227565SP
	AWS520 cable 10 m, shield connected to PE pin	229807SP
	AWS520 cable 10 m, shield not connected to PE pin	227566SP
	ROSA analog cable 10 m, cable connector, open leads on one end	231425SP
	Adapter cable for WS425 serial	227569SP
	Adapter cable for WS425 analog frequency output	227570SP
	Adapter cable for WS425 analog voltage output	227571SP
	Junction Box with Cable 2meters	ASM210719SP
	WMT700 USB service cable	240855
	Universal USB service cable with screw terminal for RS485 or RS232	240884
Mounting	WMT700 Mounting Accessories:	
	Adapter for FIX70	228869
	Fix70 (suitable also for inverted mounting)	WMT70FixSP
	Mounting adapter 60mm POM	WMT700FIX60-POMSP
	Mounting adapter 60mm RST	WMT700FIX60-RSTSP
	Cross-arm (40x40x850mm)	WMT70CROSSARM
WS425 Mounting Accessories:	Adapter for old WS425 FIX30/60	228777
	FIX30	WS425Fix30
	FIX60	WS425Fix60
	Sensor support arm for 60mm pole (655mm with integrated fix for item 228777)	WAC425