# VAISALA / APPLICATION NOTE

# Measuring Temperature and Humidity in Data Centers



Inside a typical data center.

The modern world relies heavily on the internet and online services. Increasing demand for data processing and storage capacity has led to major companies such as Google, Microsoft, and Facebook investing in new facilities that provide web-based services to an ever-higher number of users.

Data centers are energy-intensive facilities, currently consuming more than 1.3% of the world's total electricity production. This energy is transformed into heat that has to be conveyed and dissipated away from the equipment racks in order to maintain the correct operating temperature. Cooling and air conditioning is one of the most important processes in any data center.

#### **Cooling in Data Centers**

Data center cooling can be done in a variety of ways, depending on the location and the local climate. Refrigerant cooling consumes a lot of energy, but its usage can be reduced by taking the climate into consideration when choosing the location for the data center. In dry climates (with a wet bulb temperature of below 10 °C) evaporative cooling is effective at dissipating heat. In cold climates (with a temperature below 27 °C and dew point temperature below 15 °C) direct cooling with dry, cold air can be used. Locations near water offer the possibility to dissipate the heat into the water. Other key considerations include stable political and social conditions, good infrastructure, reliable power distribution, and connectivity to principal data routes.

#### The Right Temperature

The ASHRAE 2011 guidelines for conditions in data centers recommend an inlet air temperature and humidity envelope of 18 ... 27 °C and 25 ... 80 %RH (dew point temperature 5 ... 15 °C) respectively. In a traditional setup the equipment room is airconditioned by dividing the equipment into rows (hot aisles) and feeding conditioned, cool air between the rows (cold aisles), usually through the floor. When cool air travels through the equipment racks from a cold aisle to a hot aisle, it conveys the heat generated by the equipment through the ceiling. Temperature is controlled using a Computer Room Air Conditioner unit (CRAC), which performs both heating and cooling functions (though not simultaneously). For heating, the CRAC recirculates warm air from the hot aisles with cool make-up air; for cooling, incoming air is chilled to achieve the correct temperature.

#### **Measuring Humidity**

In addition to temperature, monitoring and controlling the humidity of the equipment room is also critical. Especially in cool climates where air-side economizers are used, the absolute water content of the air is naturally low. The relative humidity of air decreases when it is heated, meaning that it may fall below the desired level. Air that is too dry increases the risk of static electricity and requires additional humidification by means of spray or evaporative humidifiers.

### **Energy Savings Through** Free Cooling

When the outdoor temperature exceeds acceptable limits, the

incoming air has to be cooled. In order to minimize the need for energy-consuming mechanical refrigeration, cooling can be achieved by spraying water mist - which instantly evaporates - into the incoming air. When the humidity of the air before and after the humidifier is known, the control system is able to adjust the humidifiers to ensure maximum adiabatic cooling efficiency while maintaining the relative humidity limits and avoiding possible corrosion problems related to too high relative humidity. In systems where liquid is used as the heat carrier, the coolant may be cooled in cooling towers, which

are heat exchangers that employ a similar evaporative cooling principle. Efficient control of a cooling tower requires accurate humidity and temperature measurements, which in turn enable maximum cooling efficiency with minimized energy usage and also provides a means for monitoring the cooling power of the tower.

## Vaisala HUMICAP® — Reliable Humidity Measurements

Vaisala is a global leader in environmental measurements and has a comprehensive portfolio of products for use in data center facility management. The Vaisala offering includes instruments for measuring temperature, relative humidity, wet bulb temperature, dew point temperature, enthalpy, and weather parameters. The wide range of Vaisala HUMICAP® relative humidity and temperature instruments includes industrial-grade and HVAC transmitters that are suitable for use in data centers.

Vaisala HUMICAP® sensors are known for their accuracy, excellent long-term stability, and negligible hysteresis. Figure 1 below provides an illustration of their long-term stability in outdoor applications.




Figure 1 shows the results of an outdoor test over a period of six years, from 2008 to 2014.



Figure 2:Two HUMICAP® instruments were mounted inside a Stevenson screen on the Vaisala test grounds in Vantaa, Finland. Sensor purge was also used.

Glossary	
Dry bulb temperature	Ambient temperature.
Wet bulb temperature	Minimum achievable temperature by means of free (evaporative) cooling. The difference between the (dry bulb) temperature and wet bulb temperature represents the maximum theoretical cooling capacity of an evaporative cooler.
Dew point temperature	The temperature at which saturation is reached at the given humidity level; dew point is relevant where condensation temperatures are concerned.
Relative humidity	The level of humidity with regards to the maximum amount of humidity at a given temperature.
Enthalpy	The total heat energy (sensible heat and latent heat) involved with thermodynamic changes.



Please contact us at www.vaisala.com/requestinfo



Scan the code for more information Ref. B211471EN-A @Vaisala 2015
This material is subject to copyright protection, with all copyrights retained by Vaisala and its individual partners. All rights reserved. Any logos and/or product names are trademarks of Vaisala or its individual partners. The reproduction, transfer, distribution or storage of information contained in this brochure in any form without the prior written consent of Vaisala is strictly prohibited. All specifications — technical included — are subject