



How chemistry can help Brown Stock Washing operations

Erkki Räsänen

Antti Puustinen, Leif Robertsén, Hannu Hämäläinen, Christos Rampotas

Water is the connection

kemira

“Air is our enemy”

Forms of Air in Pulp & Paper Stock


Dissolved air

Entrained air

0-20% of the volume

Large bubbles

- Causes foam
- Easiest to get rid of




The Effect of Air Content for Washing Capacity


A high air content of pulp and wash water will have negative effect on washing capacity

Already an air content of a few percent in the pulp will significantly decrease the washing capacity of the washer

Relative capacity of a wash filter vs. air content in the pulp (drum washer)




How Defoamer Works



Deaeration

How does Defoamer affect deaeration?

What happens when a bubble meets another bubble?



Where Entrained Air and Foam are coming from?

Softwood	Hardwood
High foaming tendency	Lower foaming tendency
5 – 8 % extractives	2-4 % overall extractives. (Maple and aspen 6 -7 %)
Higher free acid content due to resin acids	More esterified fattyacids.

Mixing of air into stock or liquor!

- Filtration at washers
- Too low vat levels in washing filters
- Too low levels in filtrate tanks.
- Flashing because of too high temperature. (Boyle's law works also in practice)
- Etc...

What are the Recommended Dosing Points?

- Before process point where air can escape from the liquor at atmospheric pressure.
- Dosing to liquor/filtrate is usually better, because consistency of the pulp can be quite high.
- Better to have more feed in dosage to the first washers than at later stages.
- Dose at least 60% to the first washing stages. Mostly 70 - 80 %.
- If there is a problem with shower displacement, dosing can be done to the shower water.
- Dosing point to O₂ blow tube.

What are the defoamers to choose from?

AEROTECH 1000-series WATER BASED: Paper applications / WWT

AEROTECH 2000-series ESTER BASED: Paper applications / WWT

AEROTECH 3000-series OIL BASED: Pulp applications / WWT

AEROTECH 4000-series WATER EXTENDED OIL BASED: Pulp / WWT

AEROTECH 5000-series CONCENTRATES: Paper applications / WWT

AEROTECH 6000-series SILICONES: Pulp applications

FENNODEFO: Different industrial processes / WWT

Finland


France

Poland


USA

Canada

How to choose a defoamer? Kemira's FEAT method




Principle of defoamer testing



4. Foam disappears

5. Foam re-appears

1. Pumping started
2. Foam generated
3. Defoamer added



Performance of defoamers

Defoamer chemistry

- Type of defoamer; oil, silicone, waterbase...
- Formulation (raw materials composition)
- Colloidal characteristics (e.g. particle size)



Industrial application

- Pulp mills (black liquor, brownstock)
 - HW / SW liquors – different soaps
 - Temperature and alkali
 - Dissolved solids
- Paper mills
 - Paper grade & furnish type; extractives, dissolved colloids, calcium soaps, dissolved carbonate & microbubbles...



Selection of defoamer:

- always process-specific
- always to be optimized




Development of FEAT method

FEAT provides *responses* of defoamers


- Informative from application point of view, i.e. FEAT provides enough data for comparison of products; "foam killing efficiency"
- The relationship between chemical properties of process liquors and FEAT response curves is incomplete → there is need to measure other properties of liquors

- Dissolved solids
- Conductivity
- Dissolved ions; Na, K, Ca, SO₄...
- O₂, pH, redox (mainly wastewater applications)
- **Refractive Index**: total concentration of dissolved substances




Optimized defoamers:

- Chemistry
- Formulation
- Colloidal characteristics





From product testing to online control




Foaming →

1. Decreased washing efficiency
2. Increased carry-over





From product testing to online control



Defoaming →

1. Measurement of entrained gas
2. Measurement of dissolved substances
3. Online control of defoamer dosage



CONCLUSIONS

Brownstock operations are always impaired by

- Air, which is always present
- Overrun capacity

Chemistry can help alleviate these drawbacks

Creating a successful chemistry solution is a function of:

1. Proper chemistry testing protocol and product proposal
2. Proper system survey with sophisticated control proposal
 - Here proper instruments come into play