

# GMD20 Series Carbon Dioxide Transmitters

For Demand Controlled Ventilation Applications



#### **Features**

- · Versatile transmitters
- Reliable measurement with sensor inside the duct
- Incorporates Vaisala CARBOCAP® sensor - the silicon-based NDIR sensor
- Excellent long-term stability
- Negligible temperature dependence
- Ease of installation

The duct mounted Vaisala CARBOCAP® Carbon Dioxide Transmitter Series GMD20 is specially designed for demand controlled ventilation (DCV). The transmitters are easy to install and require no maintenance. The recommended calibration interval is five years.

## Vaisala CARBOCAP® Technology

The GMD20 series transmitters use the silicon-based Vaisala CARBOCAP® sensor. The simple structure and reference measurement capabilities make this single-beam, dual-wavelength NDIR sensor extremely stable and reliable.

The temperature and flow dependencies of the sensor are negligible. In addition, the measurement accuracy is not affected by dust, water vapor, and most chemicals.

#### **Versatile Transmitters**

The GMD20 series transmitters can be used independently, or incorporated into building energy management systems. The series consists of duct mount units GMD20 and GMD20D. Version D is equipped with a display.

The compact sensor head design of the duct units fits inside the ventilation duct, eliminating the risk of leaking gaskets and measurement errors.

In addition to the standard 0 ... 20 mA, 4 ... 20 mA, and 0 ... 10 V outputs, there are two other options: one LonWorks® interface and a relay output. The relay output is standard with the display units.

# Improve Indoor Air at Minimal Energy Costs

The use of GMD20 series transmitters ensures the best possible control of air quality and results in considerable savings in energy consumption, maintenance, and recalibration costs.

# Technical Data

#### **Measurement Performance**

#### **Carbon Dioxide**

Measurement range	0 2000 ppm (Nominal; can be calibrated for other ranges: 0 5000 ppm, 0 10 000 ppm, 0 20 000 ppm)
Accuracy (including repeatability, non- linearity and calibration uncertainty)	± (2 % of range + 2 % of reading)
Long-term stability	< ±5 % of range / 5 years
Response time (63 %)	1 minute
Warm-up time	1 minute, 15 minutes full specifications

### **Operating Environment**

Operating temperature	−5 +45 °C (+23+113 °F)
Operating humidity	0 85 %RH, non-condensing
Flow velocity	0 10 m/s
Electromagnetic compatibility	EN61326-1, Generic Environment

#### **Inputs and Outputs**


Outputs	0 20 or 4 20 mA and 0 10 V
Optional outputs	<ul> <li>Relay</li> <li>LonWorks<sup>®</sup> interface</li> </ul>
Resolution of analog outputs	8 bits
Recommended external load	• Current output: max. 500 $\Omega$ • Voltage output: min. 1 k $\Omega$
Operating voltage	Nominal 24 VAC/DC (18 30 VDC)
Connections	Screw terminals, wire size 0.5 1.5 mm <sup>2</sup>
Power consumption	< 2.5 W

#### **Mechanical Specifications**


Housing material	ABS plastic
IP rating (housing)	IP65
Weight	
GMD20 GMD20D	140 g (5 oz) 170 g (6 oz)

#### **Spare Parts and Accessories**

	Display and relay option for GMD20	GMI21
	Relay output option	GMR20
	LonWorks® module with CO <sub>2</sub> signal (not available when display option is added)	GML20
	Serial COM adapter	19040GM
	Hand-held meter for field verification	GM70



## GMD20 Dimensions



GMD20 Mounting Plate Dimensions



