
Mounting instructions for Digi One WiSP



Mounting Kit Contents




When installing unit to wallboard

First, hold plate to wall and mark appropriate holes. (See bellow) Remove plate, drill, insert supplied anchors and screws.

Slip metal plate over screws to check for proper alignment. You may wish to mark the holes then attach the logger and

You may wish to mark the holes then attach the logger and Digi unit to the plate before installing on wall.



Note: Use holes A and C
for large Digi unit,
and holes B and C for
small Digi unit

Front


Note: Screws sit out
from the wall to allow
metal plate to slip on
(A little more than plate

thickness)

IMPORTANT! To ensure proper adhesion wipe all surfaces, to which Dual Lock will be attached, with the enclosed Chempad.

When installing using 3M Dual Lock:


First wipe surface, on which the plate will be installed, with Chempad and wait until dry. Apply all 4 strips of Dual Lock to **rear** side of plate (as per drawing below). At this point you may wish to attach the logger and Digi unit to the plate before installing the plate to the surface. Remove backing strip, press plate onto surface and hold for 30 seconds.



Digi unit includes

One Digi WiSP, Serial data cable, Antenna, power adaptor.

Mounting Units on Plate:
Both the Digi WiSP and Logger units are held onto the metal plate using Dual Lock. The WiSP comes with the Dual Lock already applied. Each logger is supplied with a package including two strips of Dual Lock, a Chempad, and an instruction card. Remember to clean all surfaces with the Chempad before applying the Dual Lock.



Back of logger Dual Lock Positioning

