



Changes that can be identified with the help of the radiosonde serial number

Radiosonde serial number YWWDxxxx = lot number (YWWD) + sequential number (xxxx)

For example, the first product manufactured on Tuesday during week 14 in 2017 would be referred to as N1420001

Time of change	Radiosonde model	Short description of the change	Parameter (P/T/U/W)	No data continuity effect	2016 (M)	2017 (N)	2018 (P)	2019 (R)	2020 (S)	2021 (T)
					Sequential numbers 0001- 3000- 6000- 2999 5999 9000	Sequential numbers 0001- 3000- 6000- 2999 5999 9000	Sequential numbers 0001- 3000- 6000- 2999 5999 9000	Sequential numbers 0001- 3000- 6000- 2999 5999 9000	Sequential numbers 0001- 3000- 6000- 2999 4999 9000	Sequential numbers 0001- 3000- 6000- 2999 4999 9000
2017-10	RS41	Cover improvement; change of covers from hard plastic to EPS	-	X		Gradually from N335	All RS41-D from P071 All RS41-SG from P111 All RS41-SGM from P111 All RS41-SGP from P121	X X X	X X X	X X X

Changes that can be identified with the help of the DigiCORA® or MARWIN® sounding software version and/or a user settin

Time of change	Short description of the change	Parameter (P/T/U/W)	No data continuity effect	DigiCORA® Sounding System MW41	MARWIN® Sounding System MW32